N65518 - C172P

Fact Book



AIRSPEED LIMITATIONS

tions. The utility category maneuvering speed is 102 KIAS at 2100 pounds Airspeed limitations and their operational significance are shown in figure 2-1. Maneuvering speeds shown apply to normal category opera-

Maximum 100	VFE Maximur Speed:	200 160	V _A Maneuve	Cruising Speed		V _{NIE} Never E	e e e e e e e e e e e e e e e e e e e
10° - 30° Flaps Maximum Window Open	Maximum Flap Extended Speed: 10 ^o Flaps	2000 Pounds 1600 Pounds	Maneuvering Speed: 2400 Pounds	Cruising Speed		Never Exceed Speed	SPEED
152	108	91 81	97	123	3 1	152	KCAS
158	110	92 82	99	121	3 3	5	KIAS
with flaps down. Do not exceed this speed with windows open.	Do not exceed this speed	control movements above this speed.	Do not make full or abrupt	except in smooth air, and then only with caution.	any operation.	Do not exceed this speed in	REMARKS

Figure 2-1. Airspeed Limitations

Red Line	Yellow Arc	Green Arc	White Arc	MARKING
158	127 - 158	44 - 127	33 - 85	KIAS VALUE OR RANGE
Maximum speed for all operations.	Operations must be conducted with caution and only in smooth air.	Normal Operating Range. Lower limit is maximum weight V _S at most forward C.G. with flaps retracted. Upper limit is maximum structural cruising speed.	Full Flap Operating Range. Lower limit is maximum weight VS ₀ in landing configuration. Upper limit is maximum speed permissible with flaps extended.	SIGNIFICANCE

Figure 2-2. Airspeed Indicator Markings

POWER PLANT LIMITATIONS

Maximum Power: 160 BHP rating.

Engine Operating Limits for Takeoff and Continuous Operations:

Maximum Engine Speed: 2700 RPM. Engine Model Number: 0-320-D2J. Engine Manufacturer: Avco Lycoming.

NOTE

and mixture leaned to maximum RPM) is 2300 to 2420 RPM. The static RPM range at full throttle (carburetor heat off

Maximum Oil Temperature: 245°F (118°C). Oil Pressure, Minimum: 25 psi.

Maximum: 115 psi

Fuel Grade: See Fuel Limitations.

Oil Grade (Specification): MIL-L-6082 Aviation Grade Straight Mineral Oil or MIL-L-22851 Ash less Dispersant Oil.

Propeller Manufacturer: McCauley Accessory Division. Propeller Model Number: 1C160/DTM7557.

Propeller Diameter, Maximum: 75 inches. Minimum: 74 inches.

AIRSPEED INDICATOR MARKINGS

shown in figure 2-2. Airspeed indicator markings and their color code significance are



QQ 80

ER PLANT INSTRUMENT MARKINGS

own in figure 2-3. wer plant instrument markings and their color code significance

	RED LINE	GREEN ARC	RED LINE
TRUMENT	MINIMUM	NORMAL OPERATING	LIMIT
hometer: ea Level 000 Feet	1	2100-2450 RPM 2100-2575 RPM 2100-2700 RPM	2700 RPM
Temperature	!	100°-245°F	245°F
Pressure	25 psi	60-90 psi	115 psi
Quantity Indard anks)	E (1.5 Gal. Unusable Each Tank)	į	1
I Quantity ng Range anks)	E (2.0 Gal. Unusable Each Tank)		1
il Quantity regral Tanks)	E (3.0 Gal. Unusable Each Tank)	1	
tion	1	4.5-5.4 in. Hg	

Figure 2-3. Power Plant Instrument Markings

GHT LIMITS

WAL CATEGORY

num Ramp Weight: 2407 lbs. num Takeoff Weight: 2400 lbs. num Weight in Baggage Compartment: num Landing Weight: 2400 lbs.

ggage Area 1 (or passenger on child's seat) - Station 82 to 108: 120

₃ggage Area 2 - Station 108 to 142: 50 lbs. See following note lbs. See following note.



areas 1 and 2 is 120 lbs. The maximum combined weight capacity for baggage NOTE

UTILITY CATEGORY

Maximum Ramp Weight: 2107 lbs. Maximum Weight in Baggage Compartment: In the utility category, the Maximum Landing Weight: 2100 lbs. Maximum Takeoff Weight: 2100 lbs. baggage compartment and rear seat must not be occupied.

6 27

3

CENTER OF GRAVITY LIMITS

NORMAL CATEGORY

Center of Gravity Range: Reference Datum: Lower portion of front face of firewall. Forward: 35.0 inches aft of datum at 1950 lbs. or less, with straight line Aft: 47.3 inches aft of datum at all weights. variation to 39.5 inches aft of datum at 2400 lbs.

UTILITY CATEGORY

Reference Datum: Lower portion of front face of firewall. Center of Gravity Range: Forward: 35.0 inches aft of datum at 1950 lbs. or less, with straight line Aft: 40.5 inches aft of datum at all weights. variation to 36.5 inches aft of datum at 2100 lbs.

MANEUVER LIMITS

NORMAL CATEGORY

stalls (except whip stalls), lazy eights, chandelles, and turns in which the operations. These include any maneuvers incidental to normal flying, The normal category is applicable to aircraft intended for non-aerobatic angle of bank is not more than 60°. Aerobatic maneuvers, including spins are not approved. This airplane is certificated in both the normal and utility category.

UTILITY CATEGORY

This airplane is not designed for purely aerobatic flight. However, in Morguisition of various certificates such as commercial pilot and flight

III May 1981

structor, certain maneuvers are required by the FAA. All of these aneuvers are permitted in this airplane when operated in the utility

it be occupied. No aerobatic maneuvers are approved except those listed In the utility category, the baggage compartment and rear seat must

MANEUVER

RECOMMENDED ENTRY SPEED*

ights urns Except	2
Whip	
Stalls	
70.70	
310	
M	
HH .	
ĞĞ .	
Steep Turns	

*Abrupt use of the controls is prohibited above 99 knots.

neuvers, avoid abrupt use of controls. Intentional spins with flaps ed which in turn can impose excessive loads. In the execution of all in in aerodynamic design and will build up speed quickly with the nose inded are prohibited. m. Proper speed control is an essential requirement for execution of portant thing to bear in mind in flight maneuvers is that the airplane is maneuver, and care should always be exercised to avoid excessive Aerobatics that may impose high loads should not be attempted. The

GHT LOAD FACTOR LIMITS

RMAL CATEGORY

ht Load Factors (Maximum Takeoff Weight - 2400 lbs.): Flaps Up+3.8g, -1.52g Flaps Down+3.0g	TY AAO OF CALLES	Flans Down	ht Load Facto
(Maximum Takeoff Weight - 2400 lbs.): +3.0c +3.0c			SIC
Maximum Takeoff Weight - 2400 lbs.): +3.0c +3.0c	•		2
ximum Takeoff Weight - 2400 lbs.): +3.0c +3.0c	•	•	M
imum Takeoff Weight - 2400 lbs.): +3.8g, -1.52g			M
um Takeoff Weight - 2400 lbs.):	٠		B
n Takeoff Weight - 2400 lbs.):			E
Takeoff Weight - 2400 lbs.):		•	B
keoff Weight - 2400 lbs.):		•	T _a
off Weight - 2400 lbs.):	•		ke
Y Weight - 2400 lbs.):			ğ
Weight - 2400 lbs.):	•	•	1-16
night - 2400 lbs.): 	•	•	₩e
ht - 2400 lbs.): +3.8g, -1.52g +3.0g	٠		60
- 2400 lbs.): +3.8g, -1.52g +3.0g			Ħ
2400 lbs.): +3.8g, -1.52g +3.0g	•	•	1
00 lbs.): . +3.8g, -1.52g . +3.0g	•		22
lbs.): +3.8g, -1.52g +3.0g	•	•	8
-1.52g	+3.0g	+3.88,	lbs.):
	,	-1.52g	

tructure meets or exceeds design loads. The design load factors are 150% of the above, and in all cases, the

ITY CATEGORY

T. S. C. C. C. S. C.	Tlans Down	t Load Factors (Maximum Takeoff Weight - 2100 lbs.):
•	•	SI
		0
		M
		X
		Ħ
•		E
•		B
		Te
		K
		ğ
•		H
		Me
		e e
		F
		1
		50
•		8
+3.0g	+4.48,	lbs.):
	-1.76g	

ructure meets or exceeds design loads. The design load factors are 150% of the above, and in all cases, the

12 May 1981

KINDS OF OPERATION LIMITS

MODEL 172P CESSNA

ence to types of flight operations on the operating limitations placard required instrumentation and equipment for these operations. The referreflects equipment installed at the time of Airworthiness Certificate The airplane is equipped for day VFR and may be equipped for night VFR and/or IFR operations. FAR Part 91 establishes the minimum

Flight into known icing conditions is prohibited.

FUEL LIMITATIONS

2 Standard Tanks: 21.5 U.S. gallons each Total Fuel: 43 U.S. gallons.

Unusable Fuel: 3 U.S. gallons. Usable Fuel (all flight conditions): 40 U.S. gallons.

2 Long Range Tanks: 27 U.S. gallons each Total Fuel: 54 U.S. gallons. Usable Fuel (all flight conditions): 50 U.S. gallons.

2 Integral Tanks: 34 U.S. gallons each. Unusable Fuel: 4 U.S. gallons.

Total Fuel: 68 U.S. gallons.

Unusable Fuel: 6 U.S. gallons. Usable Fuel (all flight conditions): 62 U.S. gallons.

NOTE

place the fuel selector valve in either LEFT or RIGHT minimize cross-feeding when parked on a sloping surface, To ensure maximum fuel capacity when refueling and

Takeoff and land with the fuel selector valve handle in the BOTH position.

Maximum slip or skid duration with one tank dry: 30 seconds.

operating on either left or right tank in level flight. With 1/4 tank or less, prolonged uncoordinated flight is prohibited when

(red line) cannot be safely used in flight Fuel remaining in the tank after the fuel quantity indicator reads empty

Approved Fuel Grades (and Colors): 100LL Grade Aviation Fuel (Blue).

100 (Formerly 100/130) Grade Aviation Fuel (Green).

3. Near fuel tank filler cap (standard tanks):	CTION 2 MITATIONS	
	CESSNA MODEL 1721	
190 POTING	GESSNA MODEL 172P	
20 POINING MAYOUTE		

120 POUNDS MAXIMUM BAGGAGE AND/OR AUXILIARY PASSENGER FORWARD OF BAGGAGE DOOR LATCH

LIMITATION 8

BAGGAGE AFT OF BAGGAGE DOOR LATCH 50 POUNDS MAXIMUM

MAXIMUM 120 POUNDS COMBINED

Near fuel tank filler cap (long range tanks):

100LL/100 MIN. GRADE AVIATION GASOLINE

FUEL

CAP. 27 U.S. GAL.

100LL/100 MIN. GRADE AVIATION GASOLINE CAP. 21.5 U.S. GAL.

FUEL

FOR ADDITIONAL LOADING INSTRUCTIONS SEE WEIGHT AND BALANCE DATA

- magnetic compass in 30° increments. A calibration card must be provided to indicate the accuracy of the
- œ On oil filler cap:

OIL 7 QTS

Near fuel tank filler cap (integral tanks):

CAP. 24.0 U.S. GAL. TO BOTTOM OF FILLER COLLAR

100LL/100 MIN. GRADE AVIATION GASOLINE CAP. 34 U.S. GAL.

FUEL

9 On control lock:

REMOVE BEFORE STARTING ENGINE CONTROL LOCK CAUTION

10. Near airspeed indicator

MANEUVER SPEED - 99 KIAS

4 Near wing flap switch: AVOID SLIPS WITH FLAPS EXTENDED

OT. On flap control indicator:

0° to 10° code and 110 kt callout; also, mechanical detent at 10°.) (Partial flap range with blue color

color code and 85 kt callout; also, (Indices at these positions with white mechanical detent at 10° and 20°.)

10° to 30°

12 May 1981

12 May 1981

2-13/(2-14 blank)

2-12

BLE OF CONTENTS (Continued)

			Leaning With A Cessua Document		oute Crimin	1	Crosswind 7	Wing Flap Settings	Power Check	. TTOO		Alternator Check	Magneto Check	Warm-Up	Te Takeon	· Sun	21	
			ज र		-		Ė.	Ξ	H			5	0	ਰ	Ö			
			8		5		0	0	90			7	먑		-	٠.		
			8				Takeof	8	7	Ť.		냺	9		•			
			-				F	2				ğ	Ħ					
			Jan 1	1.			8	E				ř						
	-		- 5	5.			Ħ	떯										
		*	2					-	11.7									
			-				•											
			9					•				•	-					
			- 5	3.				*			•	•	•	•				
			3	2					1	•		•	•	•	3		•	
				5				•		•	•	•				•	•	
			1	3							•				15	•	•	
				4								•				•		
•				z										1		•	•	
•				×												•		
•	9	•		E														
•		•	•	re	•													
		•	•	H	•	•					-	1000						
3			•	0		•	8		•	•								
	•	•		ö					•	•	18							
	•	•		20	. •	•		•	•	•				•	8	20	30	
				S				•	•	•			•	•		•	2	
				F	1.			•	•	•		•	•	•	•	•		
				č	9.			•		•		•	•	•	•	•	18	•
				F	٦.	lyg	•		•			•	•	•	٠	•		•
				-	٠.						10.		•	•	•	•		•
													•	•				
100	4-20		7 10					4-10	1	4-15	4-14	4-14	4-19	4		4	4-14	4-12

INTRODUCTION

Page

can be found in Section 9. of normal operation. Normal procedures associated with optional systems Section 4 provides checklist and amplified procedures for the conduct

SPEEDS FOR NORMAL OPERATION

weight of 2400 pounds and may be used for any lesser weight. However, to achieve the performance specified in Section 5 for takeoff distance, the speed appropriate to the particular weight must be used. Unless otherwise noted, the following speeds are based on a maximum

Speed at 50 Feet 70-80 KIAS 56 KIAS 75-85 KIAS 70-80 KIAS 76-80 KIAS 76-80 KIAS 76-80 KIAS 60 KIAS 60 KIAS 65-75 KIAS 60-70 KIAS 61 KIAS 61 KIAS 61 KIAS 61 KIAS 61 KIAS 62 KIAS 92 KI	Maximum Demonstrated Crosswind Velocity: Takeoff or Landing	1600 Lbs	2000 Lbs		waximum Recommended Turbulent Air Penetration Speed:	Maximum Power, Flaps 20°	Balked Landing:	Normal Approach, Flaps 30°	Normal Approach, Flaps Up	Landing Approach:	Best Angle of Climb, Sea Level	Best Rate of Climb, 10,000 Feet	Best Rate of Climb, Sea Level .	Normal, 10,000 Feet	Normal, Sea Level	Short Field Takeoff, Flaps 10°, Speed at 50 Feet	Normal Climb Out	Takeoff:
70 Feet Tration Speed:	· el			1	F			:	:	:	:	:		:	•	ee	•	
70 Feet Tration Speed:	. 6				Pe											Q	•	
70 Feet Tration Speed:	• প্র				ne											13		
			•	•	H											0		
	•	•	•	•	ati				•							펄		
	•	•	•		0											ě		
	•	•	•	•	70				•									**
		•	•		ğ				•				•					
		•		•	ğ													
70-80 KIAS . 56 KIAS 75-85 KIAS 70-80 KIAS 76 KIAS 76 KIAS 60 KIAS 60 KIAS 65 KIAS 65 KIAS 61 KIAS		•	•	•		•												
	15 KNOTS	. 82 KIAS	. 92 KIAS	. 99 KIAS		. 55 KIAS	. 61 KIAS	60-70 KIAS	65-75 KIAS	. 65 KIAS	. 60 KIAS		. 76 KIAS		75-85 KIAS	. 56 KIAS	70-80 KIAS	

ise Characteristics st Weather Operation

Flight Operations

Starting . .

Id Weather Operation

Balked Landing

Crosswind Landing Short Field Landing Normal Landing

> 4-21 4-21

4-24 4-24 4-22 ns

ding .



b

CHECKLIST PROCEDURES

PREFLIGHT INSPECTION

1) CABIN

- Pilot's Operating Handbook -- AVAILABLE IN THE AIRPLANE
- Parking Brake -- SET.
- Control Wheel Lock -- REMOVE
- Ignition Switch -- OFF.
- Avionics Power Switch -- OFF
- Master Switch -- ON.

WARNING

stand, nor allow anyone else to stand, within the arc of the malfunction could cause the propeller to rotate. propeller, since a loose or broken wire or a component treat the propeller as if the ignition switch were on. Do not power source, or pulling the propeller through by hand, When turning on the master switch, using an external

- Fuel Quantity Indicators -- CHECK QUANTITY.
- Avionics Cooling Fan -- CHECK AUDIBLY FOR OPERATION.
- 10.87 Master Switch -- OFF.
- Static Pressure Alternate Source Valve (if installed) -- OFF.
- Fuel Selector Valve -- BOTH.
- Baggage Door -- CHECK, lock with key if child's seat is to be

NOTE

If a night flight is planned, check operation of all lights, and make sure a flashlight is available. within 30 seconds with battery and pitot heat switches on. check that pitot heater (if installed) is warm to touch internal accumulations of ice or debris. Prior to flight, surfaces. Also, make sure that control surfaces contain no tions of frost, ice or snow from wing, tail and control operations. In cold weather, remove even small accumulaupper wing surfaces for visual checks and refueling assist handles (if installed) will simplify access to the Visually check airplane for general condition during walk-around inspection. Use of the refueling steps and

Figure 4-1. Preflight Inspection

Control Surfaces -- CHECK freedom of movement and security Tail Tie-Down -- DISCONNECT Rudder Gust Lock -- REMOVE.

2 EMPENNAGE

- (3) RIGHT WING Trailing Edge
- Aileron -- CHECK freedom of movement and security

(4) RIGHT WING

- Wing Tie-Down -- DISCONNECT.

 Main Wheel Tire -- CHECK for proper inflation.

- co further samples until there is no evidence of water contamination cup) to check for water, sediment, and proper fuel grade before first Fuel Tank Sump Quick-Drain Valve -- DRAIN fuel (using sample flight of day and after each refueling. If water is observed, take
- If water is observed, take further samples until there is no evidence proper fuel grade before first flight of day and after each refueling DRAIN fuel (using sampler cup) to check for water, sediment, and Fuel Selector Quick-Drain Valve (located on bottom of fuselage)-
- Fuel Quantity -- CHECK VISUALLY for desired level. of water contamination.
- 9 01 Fuel Filler Cap -- SECURE

(5) NOSE

- dipstick/filler cap SECURE. Do not operate with less than five Engine Oil Dipstick/Filler Cap -- CHECK oil level, then check
- N quarts. Fill to seven quarts for extended flight. Fuel Strainer Drain Knob -- PULL OUT for about four seconds to contain additional water, and further draining of the system at the strainer drain CLOSED. If water is observed, the fuel system may day and after each refueling. Return drain knob full in and check clear strainer of possible water and sediment before first flight of strainer, fuel tank sumps, and fuel selector quick-drain valve must be accomplished,
- Propeller and Spinner -- CHECK for nicks and security
- 2 4 Carburetor Air Filter -- CHECK for restrictions by dust or other oreign matter.
- Nose Wheel Strut and Tire -- CHECK for proper inflation
- Nose Tie-Down -- DISCONNECT.
- 7 9 5 Static Source Opening (left side of fuselage) -- CHECK for stop-

6) LEFT WING

- Main Wheel Tire -- CHECK for proper inflation.
- SO !-Fuel Tank Sump Quick-Drain Valve -- DRAIN fuel (using sampler cup) to check for water, sediment, and proper fuel grade before first flight of day and after each refueling. If water is observed, take further samples until there is no evidence of water contamination
- 12 4 Fuel Quantity -- CHECK VISUALLY for desired level.
- Fuel Filler Cap -- SECURE.

7)LEFT WING Leading Edge

- 100 Pitot Tube Cover -- REMOVE and check opening for stoppage
- Fuel Tank Vent Opening -- CHECK for stoppage



MODEL 172P

ω

CESSNA

- Stall Warning Opening -- CHECK for stoppage. To check the system, place a clean handkerchief over the vent opening and apply suction; a sound from the warning horn will confirm system operation.
- Wing Tie-Down -- DISCONNECT.
- Landing Light(s) -- CHECK for condition and cleanliness of cover

(8) LEFT WING Trailing Edge

Aileron -- CHECK for freedom of movement and security

BEFORE STARTING ENGINE

- Preflight Inspection -- COMPLETE
- Passenger Briefing -- COMPLETE.
 Seats, Seat Belts, Shoulder Harnesses -- ADJUST and LOCK.
- H 04 00 41 10
 - Brakes -- TEST and SET.
- Avionics Power Switch -- OFF.

CAUTION

start to prevent possible damage to avionics. The avionics power switch must be OFF during engine

- Circuit Breakers -- CHECK IN.
- 00 -7 00 Electrical Equipment, Autopilot (if installed) -- OFF.
- Fuel Selector Valve -- BOTH.

STARTING ENGINE

- Prime -- AS REQUIRED (2 to 6 strokes; none if engine is warm)
- Carburetor Heat -- COLD
- Throttle -- OPEN 1/8 INCH.
- Mixture -- RICH.
- Propeller Area -- CLEAR.
- Master Switch -- ON.
- 00 -1 00 51 Ignition Switch -- START (release when engine starts).
- Oil Pressure -- CHECK.
- Avionics Power Switch -- ON.
- Navigation Lights and Flashing Beacon -- ON as required
- Radios -- ON



12 May 1981

4-6

ORE TAKEOFF

- Seats, Seat Belts, Shoulder Harnesses -- CHECK SECURE.
- Cabin Doors -- CLOSED and LOCKED.
- Flight Controls -- FREE and CORRECT
- Fuel Quantity -- CHECK. Flight Instruments -- CHECK and SET
- Mixture -- RICH.
- Fuel Selector Valve -- RECHECK BOTH.
- Throttle -- 1700 RPM. Elevator Trim and Rudder Trim (if installed) -- SET for takeoff.
- Magnetos -- CHECK (RPM drop should not exceed 125 RPM on either magneto or 50 RPM differential between magnetos)
- Carburetor Heat -- CHECK (for RPM drop)
- Suction Gage -- CHECK.
- Throttle -- 1000 RPM or LESS. Engine Instruments and Ammeter -- CHECK
- Throttle Friction Lock -- ADJUST
- Radios and Avionics -- SET. Strobe Lights (if installed) -- AS DESIRED
- Autopilot (if installed) -- OFF.
- Air Conditioner (if installed) -- OFF.
 Wing Flaps -- SET for takeoff (see Takeoff checklists).

Brakes -- RELEASE.

MAL TAKEOFF

EOFF

- Wing Flaps -- 0° 10°.
- Carburetor Heat -- COLD.
- Throttle -- FULL OPEN.
- Elevator Control -- LIFT NOSE WHEEL (at 55 KIAS).
- Climb Speed -- 70-80 KIAS

RT FIELD TAKEOFF

- Wing Flaps -- 10°
- Carburetor Heat -- COLD
- Brakes -- APPLY.
- Throttle -- FULL OPEN.

 Mixture -- RICH (above 3000 feet, LEAN to obtain maximum RPM).
- Elevator Control -- SLIGHTLY TAIL LOW. Brakes -- RELEASE.
- Climb Speed -- 56 KIAS (until all obstacles are cleared)

NORMAL PROCEDURES

ENROUTE CLIMB

- Airspeed -- 70-85 KIAS
- NOTE
- shown in the Rate Of Climb chart in Section 5. If a maximum performance climb is necessary, use speeds
- Throttle -- FULL OPEN.
- Mixture -- RICH (above 3000 feet, LEAN to obtain maximum RPM).

CRUISE

- Power -- 2100-2700 RPM (no more than 75% is recommended).
- Elevator and Rudder Trim (if installed) -- ADJUST.
- Mixture -- LEAN.

DESCENT

- Fuel Selector Valve -- BOTH.
- Power -- AS DESIRED.
- Mixture -- ADJUST for smooth operation (full rich for idle power). Carburetor Heat -- FULL HEAT AS REQUIRED (to prevent carburetor icing).

BEFORE LANDING

- Seats, Seat Belts, Shoulder Harnesses -- SECURE Fuel Selector Valve -- BOTH.
- Mixture -- RICH.
- Carburetor Heat -- ON (apply full heat before reducing power).
- Autopilot (if installed) -- OFF.
- Air Conditioner (if installed) -- OFF.

LANDING

NORMAL LANDING

- Airspeed -- 65-75 KIAS (flaps UP)
- Wing Flaps -- AS DESIRED (0°-10° below 110 KIAS, 10°-30° below
- Airspeed -- 60-70 KIAS (flaps DOWN) 85 KIAS).

Touchdown -- MAIN WHEELS FIRST. Landing Roll -- LOWER NOSE WHEEL GENTLY. Braking -- MINIMUM REQUIRED.

SHORT FIELD LANDING

- Airspeed -- 65-75 KIAS (flaps UP). Wing Flaps -- FULL DOWN (30°).
- Airspeed -- 61 KIAS (until flare).

 Power -- REDUCE to idle after clearing obstacle.
- Touchdown -- MAIN WHEELS FIRST.
- Wing Flaps -- RETRACT. Brakes -- APPLY HEAVILY.

BALKED LANDING

- Carburetor Heat -- COLD. Throttle -- FULL OPEN.
- Wing Flaps -- 20° (immediately). Climb Speed -- 55 KIAS.
- Wing Flaps -- 10° (until obstacles are cleared). RETRACT (after reaching a safe altitude and 60

KIAS).

AFTER LANDING

- Carburetor Heat -- COLD.
- Wing Flaps -- UP.

SECURING AIRPLANE

- Parking Brake -- SET.
- Avionics Power Switch, installed) -- OFF. Electrical Equipment, Autopilot (if
- Mixture -- IDLE CUT-OFF (pulled full out).
- Ignition Switch -- OFF.
- Master Switch -- OFF.
- Control Lock -- INSTALL.

AIRSPEED CALIBRATION

NORMAL STATIC SOURCE

CONDITION: Power required for level flight or maximum rated RPM dive.

9		9			
KIAS KCAS	FLAPS 30°	KIAS	FLAPS 10°	KIAS	FLAPS UP
40		44		56	
55 55		ପ୍ତ ପ୍ର		28	
60		200		70	
70		70		79	
88		80 79		8 9	
8 8 8		90		100 98	
1 1		100 98		110 107	
11		110 108		120 117	
11		11		130 126	
1 1		1 1		140 135	
::		11		150 145	
11				160	

Figure 5-1. Airspeed Calibration (Sheet 1 of 2)



Ħ o

STALL SPEEDS

DITIONS:

ES:
Altitude loss during a stall recovery may be as much as 230 feet.
KIAS values are approximate.



,				A	ANGLE OF BANK	F BANI			
EIGHT	FLAP DEFLECTION		00	3	30°	4	450		600
6		KIAS	KIAS KCAS		KIAS KCAS KIAS KCAS	KIAS	KCAS	KIAS KCAS	S
	Ę	4	51	47	55	52	61	62	10
2400	100	35	48	38	52	42	57	49	~
	300	ಜ	46	35	49	39	55	47	







WIND COMPONENTS

Maximum demonstrated crosswind velocity is 15 knots (not a limitation). NOTE:





Figure 5-4. Wind Components



VEIGHT LBS

DEFLECTION

KIAS

KCAS

KIAS

KCAS

KIAS

KCAS

KIAS

KCAS

83 56 55

74

FLAP

8

300

450

600

ANGLE OF BANK

MOST FORWARD CENTER OF GRAVITY

2400

37 4

53 56

4 55

무 9

> 52 49

300

မ္သ

မ္မ 8 47

39

47 55 83

65 69

5-12

SECTION PERFORMANCI

TAKEOFF DISTANCE **MAXIMUM WEIGHT 2400 LBS**

SHORT FIELD

CONDITIONS:

Flaps 100

Full Throttle Prior to Brake Release Paved, Level, Dry Runway Zero Wind


NOTES:

Short field technique as specified in Section 4.

- Prior to takeoff from fields above 3000 feet elevation, the mixture should be leaned to give maximum RPM in a full throttle,
- Decrease distances 10% for each 9 knots headwind. For operation with tailwinds up to 10 knots, increase distances by 10% for each 2 knots.
- For operation on a dry, grass runway, increase distances by 15% of the "ground roll" figure.

	SPI	EOFF	PRESS		0°C		10°C		20°C		30°C		40°C
WEIGHT LBS	LIFT OFF	AS AT 50 FT	ALT FT	GRND ROLL	TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS
2400	51	56	S.L. 1000 2000 3000 4000 5000 6000 7000 8000	795 875 960 1055 1165 1285 1425 1580 1755	1460 1605 1770 1960 2185 2445 2755 3140 3615	860 940 1035 1140 1260 1390 1540 1710 1905	1570 1725 1910 2120 2365 2660 3015 3450 4015	925 1015 1115 1230 1355 1500 1665 1850 2060	1685 1860 2060 2295 2570 2895 3300 3805 4480	995 1090 1200 1325 1465 1620 1800 2000	1810 2000 2220 2480 2790 3160 3620 4220	1065 1170 1290 1425 1575 1745 1940	1945 2155 2395 2685 3030 3455 3990

Figure 5-5. Takeoff Distance (Sheet 1 of 2)









SHORT FIELD

REFER TO SHEET 1 FOR APPROPRIATE

WEIGHT	SPI	EOFF EED AS	PRESS	0°C		10°C		20°C		30°C		40°C		
LBS	LIFT OFF	AT 50 FT	ALT FT	GRND ROLL	TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TO C TO C 50 FT	TAL LEAR OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS
2200	49	54	S.L. 1000 2000 3000 4000 5000 6000 7000 8000	650 710 780 855 945 1040 1150 1270 1410	1195 1310 1440 1585 1750 1945 2170 2440 2760	700 765 840 925 1020 1125 1240 1375 1525	1280 1405 1545 1705 1890 2105 2355 2655 3015	750 825 905 995 1100 1210 1340 1485 1650	1375 1510 1660 1835 2040 2275 2555 2890 3305	805 885 975 1070 1180 1305 1445 1605 1785	16	00 65 75 55	865 950 1045 1150 1270 1405 1555 1730 1925	1575 1735 1915 2130 2375 2665 3020 3450 4005
2000	46	51	S.L. 1000 2000 3000 4000 5000 6000 7000 8000	525 570 625 690 755 830 920 1015	970 1060 1160 1270 1400 1545 1710 1900 2125	565 615 675 740 815 900 990 1095 1215	1035 1135 1240 1365 1500 1660 1845 2055 2305	605 665 725 800 880 970 1070 1180 1310	1110 1215 1330 1465 1615 1790 1990 2225 2500	650 710 780 860 945 1040 1150 1275 1410	118 129 142 157 173 192 214 240 271	95 25 70 35 25 45	695 765 840 920 1015 1120 1235 1370 1520	1265 1385 1525 1685 1865 2070 2315 2605 2950

ECTION 5 'ERFORMANCE

MAXIMUM RATE OF CLIMB

CONDITIONS:

dixture leaned above 3000 feet for maximum RPM. JOTE:

WEIGHT

PRESS ALT FT

SPEED KIAS

-20°C

000

20°C

40°C

RATE OF CLIMB - FPM

2400

S.L. 2000 4000 6000 10,000 12,000

905 695 695 485 380 175

745 640 535 430 330 125

580 480 375 275 175

525 420 320 220

Figure 5-6. Maximum Rate of Climb



TIME, FUEL, AND DISTANCE TO CLIMB

CONDITIONS:



Standard	Full Thro	Flaps Up
Temperature	ttle	

	-	ON	2
Oliversin	Add		OTES.
l	=		
N. or other Designation of the last	gallons o		
	of fuel		
	ġ,		
	engine start,		
•	Xet	2000	
,	and t		
	 Add 1.1 gallons of fuel for engine start, taxt and takeon allowance. 	of Illianos	

- Mixture leaned above 3000 feet for maximum RPM.

 Increase time, fuel and distance by 10% for each 10°C above standard temperature.

 Distances shown are based on zero wind.

Figure 5-7. Time, Fuel, and Distance to Climb

5-16

CRUISE PERFORMANCE

CONDITIONS: 2400 Pounds

PRESSURE ALTITUDE

RPM

BHP%

KTAS

GPH

BHP

KTAS

GPH

BHP%

KTAS

GPH

2000

2500 2400 2300 2100

58 52

999110

6.6 6.0

55289

91 93 14

855672

896 896 896

20°C ABOVE STANDARD TEMP	STANDARD TEMPERATURE	20°C BELOW STANDARD TEMPERATURE		00 500105
	Ciuise)	Recommended Lean Mixture (See Section 4, Cruise)	I Lean	Recommended

Cruise)		
		TI CITIESTE OF
		-
	-	1
	1	-



45 MINUTES RESERVE 40 GALLONS USABLE FUEL RANGE PROFILE

2400 Pounds CONDITIONS:


Recommended Lean Mixture for Cruise


Standard Temperature Zero Wind

distance during climb. This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the NOTE:









12,000

559467

1114 105 98

55000

80391

2828

2001

55000

10,000

2500 2400 2300 2200

555 674

930621

550570

455547

1117 105 105 98

7.1 6.5 5.7

45556

88265

8000

2650 2600 2500 2400 2300 2200

558877

95

8.7 7.8 6.4 6.0

588837

106 106 93

56.7426

28888

97 97 97

5.06.57.8

6000

2500 2500 2400 2300 2100

54 54 54 54

96364

5.7.42

4555887

119 113 107 107 88

55.6.40

899982

118 112 106 99 92 86

558274

4000

25500 25000 24000 23000 21000

562

98 200

5.8 5.8 5.8 5.8

855633

1117 108 102 102 89

5.7 5.7 5.7


455882

88 94 107 1136

5.59







ALTITUDE - FEET 10,000 12,000 4000 6000 8000 **→KTAS** -KTAS-120 POWER -KTAS 105 109 1101 KTAS 8 88 KTAS-

RANGE - NAUTICAL MILES

450 KTAS-

500

550 KTAS-

KTAS

Figure 5-9. Range Profile (Sheet 1 of 3)

Figure 5-8.

Cruise Performance

5-18

Figure 5-10. Endurance Profile (Sheet 3 of 3)

12 May 1981

18 May 1981

ENDURANCE - HOURS

00

9

0

ENDURANCE PROFILE 45 MINUTES RESERVE 62 GALLONS USABLE FUEL

 $\Gamma E\colon$; chart allows for the fuel used for engine start, taxi, takeoff and climb, and a during climb.

the

12,000

10,000

8000

ommended Lean Mixture for Cruise idard Temperature

) Pounds

MODEL 172P

CESSNA MODEL 172P

LANDING DISTANCE

SHORT FIELD

CONDITIONS: Flaps 30°

Power Off Maximum Braking Paved, Level, Dry Runway

Zero Wind NOTES:

Short field technique as specified in Section 4.

Decrease distances 10% for each 9 knots headwind. For operation with tailwinds up to 10 knots, increase distances by 10%

For operation on a dry, grass runway, increase distances by 45% of the "ground roll" figure.

ALTITUDE - FEET

6000

POWER

65% POWER

POWER

4000

2000

S.L.

6

If a landing with flaps up is necessary, increase the approach speed by 7 KIAS and allow for 35% longer distances.

	SPEED	PRESS	0°C		10°C		20°C			30°C	40°C	
WEIGHT LBS	50 FT KIAS	ALT FT	GRND ROLL	TOTAL TO CLEAR 50 FT OBS		TOTAL TO CLEAR 50 FT OBS		TOTAL TO CLEAR 50 FT OBS	GRND ROLL	TOTAL TO CLEAR 50 FT OBS		TOTAL TO CLEAR 50 FT OBS
2400	61	S.L. 1000 2000 3000 4000 5000 6000 7000 8000	510 530 550 570 595 615 640 665 690	1235 1265 1295 1330 1365 1400 1435 1475 1515	530 550 570 590 615 640 660 690 715	1265 1295 1330 1360 1400 1435 1470 1515 1555	550 570 590 615 635 660 685 710 740	1295 1325 1360 1395 1430 1470 1510 1550 1595	570 590 610 635 660 685 710 735 765	1325 1360 1390 1430 1470 1510 1550 1590 1635	585 610 630 655 680 705 730 760 790	1350 1390 1425 1460 1500 1540 1580 1630 1675

Figure 6-7. Center of Gravity Moment Envelope

LOADED AIRPLANE MOMENT/1000 (POUND-INCHES)

WEIGHT & BALANCE EQUIPMENT LIS

SECTION

MODEL 172P CHESNA

The following equipment list is a comprehensive list of all Cessna equipment available for this airplane. A separate equipment list of items installed in your specific airplane is provided in your aircraft file. The following list and the specific list for your airplane have a similar order of listing.

EQUIPMENT LIST

This equipment list provides the following information:

item. Suffix letters are as follows: prefixed with a letter which identifies the descriptive grouping (example: A. Powerplant & Accessories) under which it is listed. Suffix letters identify the equipment as a required item, a standard item or an optional An item number gives the identification number for the item. Each number is

-R = required items of equipment for FAA certification

-O = optional equipment items replacing required or standard -S = standard equipment items

-A = optional equipment items which are in addition to required or standard items

A reference drawing column provides the drawing number for the item.

NOTE

tions, or a separate FAA approval. accordance with the reference drawing, accessory kit instruc-If additional equipment is to be installed, it must be done in

and center of gravity location for the equipment. Columns showing weight (in pounds) and arm (in inches) provide the weight

NOTE

values) for the weight and arm are shown. Positive arms are distances aft of the airplane datum; negative arms are distances forward of the datum. Unless otherwise indicated, true values (not net change

complete assembly installation. tion of these major components does not necessarily equal the bly are listed on the lines immediately following. The summaassembly installations. Some major components of the assem-Asterisks (*) after the item weight and arm indicate complete

